# Baby Lock
# Sewing Accessories

## Blind Stitch Foot

**(BLG-BSF)**

## Instructions

Looking for a quick and easy way to make your hems invisible? This replacement foot was designed specifically for easily stitching a blind stitch. You can also use this foot for quick edge stitching.

**INSTRUCTIONS:**

1. Select a basting stitch or set your straight stitch to the longest stitch length.

2. Place the fabric wrong side up, fold and baste the fabric.




① 5 mm (approx. 3/16 inch)
② Basting stitches
③ Wrong side of fabric

3. Fold the fabric again.




① 5 mm (approx. 3/16 inch)
② Wrong side of fabric
③ Basting stitches

4. Select a blind hem stitch.




5. Attach the Blind Stitch Foot and lower the presser foot. Position the fabric so the folded edge touches the guide of the presser foot.




① Guide
② Fold

baby lock

FOR THE LOVE OF SEWING



800-422-2952 www.babylock.com

6. Sew the fabric, keeping in the folded edge in contact with the presser foot.




① Needle position

7. Remove the basting stitches and turn the fabric over.




① Wrong side of fabric
② Right side of fabric

**Note:** Blind hem stitches cannot be sewn if the left needle drop point does not catch the fold. If the needle catches too much of the fold, the fabric cannot be unfolded and the seam appearing on the right side of the fabric will be very large, leaving an unattractive finish. If you experience either of these cases, follow the instructions below to solve the problem.

**If the needle does not catch the fold**
Adjust the width so that the needle slightly catches the fold by pressing - in the width display.



**If the needle catches too much of the fold**
Adjust the width so that the needle slightly catches the fold by pressing in the width display.



baby lock

FOR THE LOVE OF SEWING

800-422-2952 www.babylock.com